




YCK-1010M YCD-1010M YCD-1315M YCK-2010M

※


※

※

※



■ 取付図



寸法：mm


型 番	取付寸法	本体定尺	寸 法
YCD-5050	8	3000	50 × 50
YCD-7070	8	3000	70 × 70
YCD-1010	10	3000	100 × 100
YCD-1010L	10	3000	100 × 100
YCD-1315	12	3000	130 × 150
YCD-1315L	12	3000	130 × 150
YCK-1010	10	3000	100 × 100
YCD-1010W	12	3000	100 × 100
YCD-1210W	12	3000	120 × 120
YCD-1415W	16	3000	150 × 150
YCD-2020W	20	3000	200 × 200
YCK-1010W	12	3000	100 × 100
YCK-1010M	12	3000	100 × 100
YCD-1010M	12	3000	100 × 100
YCD-1315M	20	3000	130 × 150

廃 盤

YCD-1010W
YCD-1210W
YCD-1415W
YCD-2020W

※

YCD-1070L



● コーナー部

